



## HL318LC Weighing Indicator

User Manual

**SH.01**

		<b>Warning</b>
		Ask professional personnel to debug, detect and repair controller.

		<b>Warning</b>
		Please keep good grounding of controller.

	<b>Warning</b>
In electrical connection of controller, please cut off the power supply in advance. Wait for 30 seconds between power-on of the controller for 2 times.	

	<b>Pay Attention to Static Electricity</b>
The controller is a device sensitive to static electricity, thus please take anti-static precautions in use and maintenance.	

# Contents

一、 TECHNICAL INDICATORS.....	3
二、 MAIN FUNCTION .....	3
三、 BOUNDARY DIMENSION .....	4
四、 INTRODUCTION TO PANEL .....	5
五、 SETTING OF PARAMETERS.....	7
ENTRY SETTING .....	
F1 SETTING OF SCALE .....	7
F2 SETTING OF APPLICATION FUNCTION.....	9
F3 SETTING OF ENERGY SAVING PARAMETERS.....	10
F4 SETTING OF SERIAL PORT .....	11
F5 MAINTENANCE AND SERVICE .....	11
六、 FUNCTION DESCRIPTION.....	12
APPENDIX 1. CONTINUOUS OUTPUT FORMAT SPECIFICATION .....	1616
APPENDIX 2. PRINTING FORMAT SPECIFICATION .....	16

## 1、 Technical Indicators

- 6-digit 1.6-inch LCD display. Long service life and shock resistance
- 7 function keys. Operation is simple and convenient
- Protection level: IP5X
- Excitation voltage: +5VDC
- Load capacity of sensor: at most 4 350Ω simulation sensors
- Input signal range of null point: 0-5mV
- Input signal range of full scale: 1-10 mV
- Inner resolution: 1 million
- Weight upgrading rate: 40 times per second
- Power supply mode

Battery: Lithium battery 7.4V4Ah

Adapter: voltage 100-240VAC    Current 0.1A    Frequency 50-60Hz.


- 2 RS232 ports
- Operating temperature: -10°C-40°C, relative humidity is below 85 %
- Storage temperature: -20°C-60°C, relative humidity is below 85 %
- Conforming to standard :GB/T 7724-1999

## 2、 Main Function

- Basic weighing function: resetting, removing the peel and clearing the peel
- Weight detection function, counting function, animal scale function
- Weight keeping function, weight accumulation function, percentage display
- Set redundant backup function of parameters
- Automatic screen protection and automatic shutdown energy-saving function
- Rich printing formats and communication protocol


### 3、 Boundary Dimension

Instrument size: detailed in the following figure (mm); instrument weight:  
1.5kg



### 4、 Connector

#### 4.1 RS232-1 and RS232-2



## 4.2 Load cell Connector

	<p>1Pin: +E      2Pin: +S      3Pin: SHLD      4Pin: -S 5Pin: +E</p>
---	--

## 5、 Introduction to Panel

- Introduction to indicator lamps

Identification	Analysis
	Sorting and weight check status indicator
<b>x10</b>	Extension indicator
	Counting scale indicator
	Animal scale indicator
	Accumulating scale indicator
	Accumulating scale adjustment display indicator
<b>HOLD</b>	Weight hold indicator
<b>NET</b>	Net weight indicator
	Scale in dynamic status
	Scale at zero indicator
	Key pressed indicator
	Battery indicator
<b>kg</b>	Weight unit

<b>PCS</b>	Counting scale unit
<b>%</b>	Weight % indicator

● Introduction to operation keys

Operation without special specification refers to short press on keys.

<b>Key symbol</b>	<b>Normal weighing state</b>	<b>Set stage</b>
	Weight maintenance key-> 『Hold』 Short press→ F2.1 = 1, keep/cancel. F2.1 = 2, switch between percentage and weight. F2.1 = 5, switch between quantity and weight. Long key→ enter setting menu.	Return to the last menu.
	Accumulation key-> 『Total』 Short key → F2.1 = 4, include display weight in accumulation value.。 F2.1 = 0 , enter into/exit the accumulation model. Long key → F2.1 = 3, select scale to sample target weight. F2.1 = 4, accumulate weight of scale display. F2.1 = 5, count sampling of scale.	No definition.
	Printing key-> 『Print』 Short key → start up of print.	Flicker bit is on the left.

	Function key-> 『Func』 Long key → Enter into setting menu.	Flicker bit is on the right.
	Tare key-> 『Tare』 Short key → gross weight turns to net weight. Indication lamp of net weight “Net” is on. Conduct skin removal operation for multiple times.	Digit flicker position reduces.
	ZERO Key-> 『Zero』 Gross weight state resets weight. When the scale is in net weight, dynamic state, saving state and out of resetting range, zero clearing operation is invalid.	In setting, digit of flicker position increases. In adjustment of display, accumulation is cleared.
	Short key → Start up. Long key → shut down.	Confirm operation, to save setting data.

## 6、Parameter Setting

### Setting entry:

Press the 『Func』 button on the operating panel in the state of normal weighing.

If F1.14 = 0, you can set all the parameters within F1~F5.

If F1.14 = 1, you can only set all parameters within F2~F5.

If F1.14 = 1 and you need to set the parameters within F1 menu, you can press the calibration switch button until the F1 menu is entered.

### F1 Parameter Setting

#### F1.1 Measuring Range

Selectable parameters: 3~200000 (default value: 6)

#### F1.2 Decimal Places

Selectable parameters: 0 ---- no decimal point

0.0 ---- 1 decimal place

0.00 ---- 2 decimal places

0.000 ---- 3 decimal places (default value)

0.0000 ---- 4 decimal places

### F1.3 Number of Divisions

Selectable parameters: 1 (default value), 2, 5, 10, 20, 50

### F1.4 Calibration Unit

Selectable parameters: 0 ---- kg (default value)

1 ---- lb

### F1.5 Gravitational Acceleration

Selectable parameters: 9.70000~9.99999. Default value = 9.79455.

### F1.6 Null-point Calibration

**【E\_5CL】** Keeping empty the scale

Remove the weights on the weighing platform to guarantee the scale is in the empty state. Press the 『ON/OFF』 key and the indicator will display **【I 0 CAL】**, The displayed digits will reduce slowly until the indicator displays **【00 CAL】**, In the end it will display **【End】** for one second, which indicates the end of null-point calibration.

### F1.7 Load-point Calibration

**【LOAD】** Loading weights

Load weights on the weighing platform to ensure that  $10\%$  of full-scale value  $\leq$  weight of weights  $\leq$  full-scale value, and then press the 『ON/OFF』 key to start the next step.

**【000000】** Entering the same weight value as that of the loaded weights.

Entering the same weight value as that of the loaded weights, please press the 『ON/OFF』 key after the scale becomes stable, and the meter will display **【I 0 CAL】**. After that, the displayed digits will reduce slowly until the meter displays

[00 CAL]. In the end it will display [End ] for one second, which indicates the end of null-point calibration.

F1.8 Automatic Null Tracking

Selectable parameters: OFF, 1 d, 2 d, 3 d, 5 d (default value)

F1.9 Automatic Reset Range at Startup

Selectable parameters: OFF, 2 %, 10 %, 20 % (default value)

F1.10 Button Reset Range

Selectable parameters: OFF, 2 %, 10 % (default value), 20 %

F1.11 Digital Filter

Selectable parameters: 0 ---- Mild Filtering

1 ---- Moderate Filtering (default value)

2 ---- Severe Filtering

F1.12 Steady Range

Selectable parameters: 1 d, 2 d, 3 d (default value)

F1.13 Overload Display Range

Selectable Parameters: 9d, 5% (default value), 10%, 20% ±120%

F1.14 F1 Menu Protection

Selectable Parameters: 0 ---- Enter F1 menu by keyboard operation

1 ---- Enter F1 menu by pressing the calibration button

F1.15 Strong filter mode

Selectable Parameters: 0 ---- Not enabled

1 ---- start using

F1.16 Restoring Factory Default

Set the parameters within F1~F4 as the defaults, which can't impact the parameters of standard scale.

## F2 Application Function Setting

F2.1 Function Selection

Selectable Parameters: 0 ---- ×10 functions

- 1 ---- Weight keeping function
- 2 ---- Percentage display function
- 3 ---- Weight checking and sorting function  
(default value)
- 4 ---- Accumulative scale function
- 5 ---- Counting scale function
- 6 ---- Animal scale function
- 7 ---- Peak holding function

F2.2 Empty-scale threshold value

Selectable Parameters: 0~ full range (default value: 0.001)

F2.3 Target Weight for Weight Checking and Sorting

Selectable Parameters: 0~ full range (default value: 2.000)

F2.4 Positive Error for Weight Checking and Sorting

Selectable Parameters: 0~ full range (default value: 0.100)

F2.5 Negative Error for Weight Checking and Sorting

Selectable Parameters: 0~ full range (default value: 0.100)

F2.6 Access to Target Weight for Weight Checking and Sorting, and Counting Sample Weight

Selectable Parameters: 0 ---- Access to Platform Weighing  
(default value)

1 ---- Manual Input Access

**F3 Energy-saving Parameter Setting**

F3.1 Automatic backlight energy-saving time setting

Parameters selectable: 0 ~ 999。

0: Backlight NC;

1: Backlight NO;

2~999: 2~999s automatic backlight (default 10s)

F3.2 Automatic OFF energy-saving time setting

Parameters settable: 0 ~ 60min. (default 5 minutes)

“0” stands for deactivation of this function.

F3.3(DATE)

F3.4(TIME)

## F4 Serial-port Setting

### F4.1 UART0 Communication Interface Parameter

#### F4.1.1 Communication Mode

Selectable Parameters:

- 0 ---- command out
- 1 ---- continuous output
- 2 ---- Key output

#### F4.1.2 Setting of Data and Check Pit

- Selectable Parameters:
- 8\_N\_1 ---- 8-pit no parity check (default value)
  - 7\_E\_1 ---- 7-pit odd parity check
  - 7\_O\_1 ---- 7-pit even parity check
  - 8\_E\_1 ---- 8-pit odd parity check
  - 8\_O\_1 ---- 8-pit even parity check

#### F4.1.3 Baud Rate

Selectable Parameters: 600, 1200, 2400, 4800, 9600 (default value)

### F4.2 Parameter Setting of UART1 Printing Interface

#### F4.2.1 Whether to connect the printer

- Selectable Parameters:
- 0 ---- not connected to the miniprinter (default)
  - 1 ---- connected to the miniprinter

#### F4.2.2 Printing Carriage Return Character

Selectable Parameters: 0~9 carriage return characters  
(default value: 3)

#### F4.2.3 Printing Setting of Accumulative Scale

- Selectable Parameters:
- 0 ---- total accumulative data for printing (default value)
  - 1 ---- printing detail + total accumulative data

#### F4.2.4 Print language setting

- Selectable Parameters:
- 0 ---- in Chinese (default)
  - 1 ---- in English  
(Eng,CH1)

## F5 Maintenance and Service

### F5.1 Key test

Instrument display【PrESS】, press 『Print』、 『Zero』、 『Tare』、 『Gross』、 『lb/kg』、 『Total』 in order, and the instrument displays 【Pr int】、 【Zero】、 【TARE】、 【Gross】、 【Unit】、 【TOTAL】 , press 『Hold』 to quit key test.

### F5.2 Display screen test

All strokes of meter display will have self-inspection, to observe whether there is lacks of strokes.

Press 『Hold』 or 『ON/OFF』 to quit test of display screen.

### F5.3 Display current internal code

The display will show internal code of current instrument after smoothing. Press 『Hold』 or 『ON/OFF』 to quit the interface.。

## 7、 Function Description

- ×10 function F2.1 = 0

#### Operation

In normal weighing mode, press 『Total』 on the operation panel once, the display accuracy will promote for 10 times and icon ×10 gets on at the same time; press the key again it returns to normal weighing mode and the icon of ×10 gets off.

- Note: 1. In net weight status, it's forbidden to change over to ×10 function status;  
2. If there have been 4 decimal places, it's forbidden to change over to ×10 function status;  
3. Under ×10 function status, both serial output and printing output are forbidden.  
4. Under ×10 function status, it's forbidden to tare.

- Weight hold function F2.1 = 1

How to operate In normal weighing mode, press 『Hold』 on the operation panel once, the weight presently displayed can be locked and “Hold” indicator gets. Weight Hold operation is valid only when the displayed weight is  $\geq$ F2.2 set value; otherwise, it displays invalid operation with 【--□□--】 for one second and the scale goes back to normal weighing mode.

If the weight is locked, press 『Hold』 again to unlock and it goes back to normal weighing mode and “Hold” indicator goes off.

In weight locked status, it refuses to tare, clear tare and zero.

- Percentage display F2.1 = 2

#### Display introduction

Displaying 【 20.5】 indicates 20.5 %.

$Pr = \text{present actual weight} / \text{measuring range} \times 100\%$

Pressing 『Hold』 key to change over between percentage and weight

- Weight check, sorting scale function F2.1 = 3

#### Function description:

Parameters as F2.2 = A, F2.3 = B, F2.4 = C, F2.5 = D etc shall be set.

Presently displayed weight is X.

If  $X \leq A$ , no weight check or sorting will be performed.

If  $X < (B - D)$ , it stands for short weight; the short-weight icon goes on.

If  $(B - D) \leq X \leq (B - C)$ , it stands for PASS; PASS icon goes on.

If  $X > (B - C)$ . It stands for overweight; overweight icon goes on.

#### Target value acquisition

Hold 『Total』 until 【TARGET】 is displayed, and then press 『ON/OFF』 ; the present target value goes on and flashes.

If F2.6 = 0, press 『ON/OFF』, the present weight on the scale will be taken as new target value and it exits setting interface.

If F2.6 = 1, it displays 【000000】 , requiring modifying the target value manually. After the modification, press 『ON/OFF』 to save the data and exit the setting interface.

Press 『Hold』 to exit target value acquisition.

- Accumulating scale function F2.1 = 4

#### How to operate

In normal weighing state, the scale is at zero; apply the scale with load and press 『Total』 on the operation panel; if it displays 【Add--】 , it means that the present weight has been counted in

the accumulated value; then it goes back to normal weighing status. If it displays **【--00--】** for one second and then goes back to normal weighing mode, it means invalid operation! Causes: 1. The scale must be zeroed between two successive accumulation operations, otherwise, accumulation will be refused. 2. Accumulation is valid only when the displayed weight is  $\geq$ F2.2 setting. 3. The scale is in dynamic status.

#### Adjusted display, clearing, and printing of accumulated value

In normal weighing mode, hold **『Total』** on the operation panel for over two seconds, it displays **【TOTAL】** for one second; then the monitor shows the present accumulated value **【 9.500】** or times of accumulation **【Cn 9】**; press **『Gross』**, **『lb/kg』** to change over; now the adjustment display icon goes on. Now if it's necessary to clear the accumulated value, press **『Zero』** to have the display becomes into "0". If F4.2.1=1, pressing **『Print』** can print the accumulated data. To exit the interface, press **『Hold』**.

Note: whether to be over the specific data and accumulated data can be set in F4.6.

#### ● Counting scale function F2.1 = 5

##### Instrument display

**【 128】**, displays the present counts

##### Sampling method

1. Check whether the scale is at Zero, otherwise, press **『Zero』**.
2. Put the counted material onto the scale platform.
3. Hold **『Total』** until **【SAMPLE】** is displayed; then press **『Print』**. If F2.6 = 0, it displays **【 000】**. Enter the value just counted and then press **『Print』** to confirm, the sampled data will be saved and the system exits sampling interface. If F2.6 = 1, it displays **【000000】**; enter the sample weight and press **『Print』**; the system saves the setting data and exits sampling setting interface.
4. In this function, press **『Hold』** to switch between counts and weight.

● Animal scale functions F2.1 = 6

Operation method

In normal weighing state, place the animal on the weighing platform and its weight must be  $\geq$  threshold value set in F2.2. Press 『Total』, instrument will collect data sampling. After sampling, the average value of sampling data will be locked, showing X.XXX kg; animal state indicator flashes. Press 『Print』 to print; press 『Hold』 or 『Total』 to quit the interface.

● 8、 Prompt Message of Instrument

The instrument has extremely high stability and reliability, thus is not easy to have error in general situation. Once an error occurs, please make clear the error first and observe whether the instrument still has error after power-on. Do not hurry to repair the scale body or instrument. Repair the instrument according to error code of the instrument as possible

No.	Symbol	Analysis	Treatment Method
1	【 _EEE 】 【 EEE 】	Unable to reset after startup	1、 Determine it is no-load state in startup; 2、 Make zero calibration again.
2	【 〰-----〰 】	The weighed object is over full range for 9d	Reduce weight on weighing platform
3	【 L-----J 】	The weighed object is below 0 for 5d	Press 『Zero』 to reset
4	【 〰-n0-〰 】 【 L-n0-J 】	Out of zero clearing range	Check whether the weighing platform has weight. Remove weight.
5	【 --n0-- 】	Invalid operation	
6	【 Err 03 】	EEPROM checksum and error	Press 『Print』 reprint factory value. Start up again. If the information occurs again, return to factory for repair. Please calibrate the scale again if the situation does not occur; <b>Attention:</b> this place is provided with all parameters of

			instruments of the factory.
7	【Err 05】	The calibration input weight is too small	Input≥10 % weight of full range
8	【Err 06】	The weight in calibration is too light	Load≥10% weight of full range
9	【Err 07】	The scale is dynamic in scale	Inspect the scale body
10	【Err 08】	Setting error of date and time	Set according to specification of date and time
11	【Err 09】	Error of AD initialization	If the error occurs after restarting, return it to the factory for repair
12	【LOAD】	In loading scale, it indicates to loading weight;	Load weight according to requirements;
13	【SETUP】	It has enters menu setting	Press 『Print』 to continue setting.
14	【End】	End of zero point and loading point calibration	
15	【Add--】	Including current display weight in accumulated value	
16	【-OVER-】	Accumulated weight overflows	Clear accumulated weight in time
17	【Ld---】	Loading default value	
18	【Print】	Printing	

## Appendix 1、UART0 Output Format Specification

### 1、UART0 output MT format

No.	mark	Bit	analyze	Re-mark
1	(	1	0x28	
2	+ OR -	1	0x2b or 0x2d	
3	)	1	0x29	
4	XXXXXXXX	7	7-bit ASCIIcode	Contains decimal

				points
5	\r	1	0x0d	
example:				
1、 0x28 0x2b 0x29 0x30 0x30 0x31 0x32 0x38 0x2e 0x35 0x0d show 128.5				
2、 0x28 0x2d 0x29 0x30 0x30 0x31 0x32 0x38 0x2e 0x35 0x0d show -128.5				
3、 0x28 0x2b 0x29 0x30 0x30 0x31 0x32 0x38 0x31 0x35 0x0d show 12815				
4、 0x28 0x2d 0x29 0x30 0x30 0x31 0x32 0x38 0x31 0x35 0x0d show -12815				

## 2、 Output description

F4.1.1 = 0, command out. "W" 57 H from host.

Output format refer to **UART0 output MT format**.

F4.1.1 = 1, continuous output.

Output format refer to **UART0 output MT format**.

F4.1.1 = 2, Key output.

Output format refer to **UART0 output MT format**.

Zero Command: "Z"(0x5a)。

Tara Command: "T"(0x54)。

Zero Command: "C"(0x43)。

## Appendix 2. Printing Format Specification

F2.1 = 0、 1、 4、 6, print current resetting, press 『Print』

REPORT	
-----	
Gross	0.200kg
Tare	0.000kg
Net	0.200kg

F2.1 = 1 weight maintenance function:

Weight is not in maintenance state:

REPORT	
-----	
Gross	0.200kg
Tare	0.000kg
Net	0.200kg

Weight is in maintenance state:

REPORT	
-----	
Gross	25.000kg
Status	Hold

or

REPORT	
-----	
Net	25.000kg
Status	Hold

F2.1 = 3 selection, check weight, press 『Print』 :

REPORT	
-----	
Gross	1.980kg
State	Less

Underweight

REPORT	
-----	
Gross	2.000kg
State	OK

Qualified

REPORT	
-----	
Gross	2.020kg
State	Over

Overweight

F2.1 = 4 accumulation scale, print detailed statement or format of total weight:

Print details and total weight

REPORT	
-----	
1	0.200kg
2	0.175kg
3	0.347kg
4	0.375kg
-----	
Count	4
Total	1.097kg

Only print total weight

REPORT	
-----	
Count	4
Total	1.097kg

F2.1 = 5 counting scale, press 『Print』 :

REPORT	
-----	
Gross	0.547kg
Amount	55